

MICRO SWITCH CAM ADJUST

Cycle of the
operation
the proper seq.

To adjust,
position (grip)
the service sca

1. Rotate the
shaft count

2. At this poi
the cam gr
down off the

